

MAYA

Item no. FR30824 / FR30825 / FR30826 / FR30827


Drawing 1 - Fixture Assembly



Drawing 2 - Fixture installation



Drawing 3 - Shade installation



start here

SAFETY WARNING: READ WIRING AND GROUNDING INSTRUCTIONS (I.S. 18) AND ANY ADDITIONAL DIRECTIONS. TURN POWER SUPPLY OFF DURING INSTALLATION. IF NEW WIRING IS REQUIRED, CONSULT A QUALIFIED ELECTRICIAN OR LOCAL AUTHORITIES FOR CODE REQUIREMENTS.

1

1. Shut off electrical current before starting. If the fixture you are replacing is turned on and off by a wall switch, simply turn the switch off. If not, remove the appropriate fuse (or open the circut breakers) until the fixture is dead.

• DO NOT restore current - either by fuse, breaker or switch - until the new fixture is completely wired and in place.

2

1. Determine the desired height the chandelier will be installed at.
2. The fixture is supplied with a variety of stem lengths. Determine what combination of stems are needed to achieve desired length - see **Drawing 1**.
3. Slip stems over wire and thread first stem onto top of chandelier. Repeat this process until all required stems are threaded together.
4. Slip wire through center of canopy swivel and thread onto stem assembly.

3

1. Prepare mounting strap **(B)** for mounting by installing screws **(A)** into mounting plate **(B)** - see **Drawing 2**.
• Be sure the holes into which the screws are threaded match the spacing of holes **(C)** in the canopy **(D)**.
2. Attach mounting plate **(B)** to junction box **(J)**, using screws **(G)** provided and slip supply wires through large center hole.

SAFETY WARNING: READ WIRING AND GROUNDING INSTRUCTIONS (I.S. 18) AND ANY ADDITIONAL DIRECTIONS. TURN POWER SUPPLY OFF DURING INSTALLATION. IF NEW WIRING IS REQUIRED, CONSULT A QUALIFIED ELECTRICIAN OR LOCAL AUTHORITIES FOR CODE REQUIREMENTS.

4

Make electrical connections from supply wire to fixture lead wires. Refer to instruction sheet **(I.S. 18)** and follow all instructions to make all necessary wiring connections. Then refer back to this sheet to continue installation of this fixture.

5

1. Hang the fixture by slipping canopy **(D)** over screws **(A)** and holding in position - see **Drawings 2.**
2. Thread ball knobs **(E)** onto end of screws **(A)** and tighten to secure fixture to ceiling.

6

1. To install shade **(1)** and glass **(2)**, first slip glass **(2)** inside shade **(1)** and align top hole in glass with center hole in shade ring **(R)**, now slip both over socket **(3)** and hold in position.
2. Slip spacer ring **(4)** over socket, then thread socket ring **(5)** onto socket **(3)** and tighten.
3. Fixture can now be lamped accordingly.
NOTE: Fixture can be assembled with shade only or glass only.

FREDRICK RAMOND
ESTABLISHED 1965
A Division of Hinkley Lighting, Inc.
33000 PIN OAK PARKWAY | AVON LAKE, OHIO 44012
toll free 800.446.5539 | *phone* 440.653.5500